



CHILD SAFETY

Blind and curtain cords have been linked to accidental child strangulations in Australia since the 1990s.

These cords pose a serious risk, especially as children can climb on furniture to reach them—even if the window seems out of reach.

To help prevent these tragedies, the ACCC has mandated warning labels and safety features like cord cleats and chain guides to stop cords from forming loops.

These labels and devices must be fitted at installation and stay in place for the life of the blind. Products that don't meet these standards can't legally be sold.

Some blinds may also include added protections, such as breakaway tassels, for extra peace of mind.

AWARNING




Young children have died by wrapping loose curtain and blind


cords or chains around their necks. Secure cords or chains with cord guides or keep them out of reach by winding them around a cleat. Move cots and furniture away from window coverings, cords or chains.

DO NOT REMOVE THIS LABEL

Fitting Instructions

- « Place the tension device at the bottom of the chain loop. (Figure 1).
- « Mount the tension device onto the reveal or frame, ensuring that the loop chain hangs with minimal tension. (Figure 2).





Still not 100% confident with your measurements? Contact your local store and talk to one of dedicated team members for assistance.







